

ASSEMBLY INSTRUCTIONS


Read this instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture part on a clean and flat soft surface to prevent scratches. Refer steps provided as assembling guide.

CAUTIONS :


1. Do not **FULLY-TIGHTEN** the nuts or nut bolts until all are in place.
2. To prevent thread damage. Ensure that nuts or nut bolts are not over-tighten.
3. Hardware are to be kept out of reach from children.

PART LIST			HARDWARE LIST		
ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY
A	HEADBOARD	1 PC	1	JCBB SCREW M8 x 16mm	8 PCS
B	SIDERAIL (L&R)	2 PCS	2	ALLEN KEY M5 (SHORT)	1 PC
C	FOOTBOARD	1 PC	3	JCBC SCREW M6 x 50MM	3 PCS
D	SLAT	14 PCS	4	JCBC SCREW M6 x 40MM	12 PCS
E	CENTER SLAT	1 PC	5	SPRING WASHER ¼ "	15 PCS
F	CENTER SLAT SUPPORT	3 PCS	6	FLAT WASHER ¼ "	12 PCS
G	LEG	2 PCS	7	PAN HEAD SCREW M4 x 25mm	6 PCS
H	LEG SUPPORT	2 PCS	8	ADJUSTER BASE GLIDE C99	3 PCS
			9	M4 ALLEN KEY (LONG)	1 PC


STEP 1



STEP 2



STEP 3



STEP 4

